

Ratchet Repair Kit

Part No.	Description
X101-RK	1″ Drive fits X101



Flex Handle Repair Kits

Kit Part No.	Fits Flex Handle Part Number
FHRK3/8	3/8″ Drive fits T30, T30B
FHRK1/2	1/2″ Drive fits 653, 653L, 653B, 653LB
FHRK3/4	3/4″ Drive fits 4288,4288B(screw & washer only)
FHRK1	1″ Drive fits X106

Repair kit consists of three parts: Head, Screw & Lock Washer.





Flex Head Ratchet Repair Parts

Part No.	Description	Fits Ratchet Part Number
T30-SCR	Screw	T37, T37X, T71, T72,
653-SCR	Screw	8798F, 677
677-LCW	Lock Washer	

Adjustable Wrench Repair Kits

Kit Part No.	Fits Wrench
65115-RK	65115
65304-RK	65304
65306-RK	65306
65308-RK	65308
65310-RK	65310
65312-RK	65312
65315-RK	65315
65318-RK	65318
65324-RK	65324

Repair kit consists of three parts: Pin, Knurl, and Spring.
Note: For jaw replacement, use wrench part number with suffix-JAW.