
REPLACEMENT PARTS


C-Clamp Spare Parts

Clamp Part No.	Lead Screw Part No.	Part No.	Spring Part No.
C402	C402-SCR	C402-PAD	C402-SPG
C403	C403-SCR	C403-PAD	C403-SPG
C404	C404-SCR	C404-PAD	C404-SPG
C406	C406-SCR	C406-PAD	C406-SPG
C408	C408-SCR	C408-PAD	C408-SPG
C410	C410-SCR	C410-PAD	C410-SPG
C412	C412-SCR	C412-PAD	C412-SPG



L-Clamp Spare Parts


Clamp Part No.	Screw Part No.	Joint Part No.	Nut Part No.	Pad Part No.	Pin Part No.
L408C	L400C-SCR	L400C-JNT	L400C-NUT	L400C-PAD	L400-PIN
L412C					
L416C					
L420C					
L408	L400C-SCR	L400C-JNT	L400C-NUT	L400C-PAD	L400-PIN
L412					
L416					
L420					



Lever Clamp Repair Kits

Repair Kit Part No.	Fits Clamp Part No.
L508-RK	L508
L512-RK	L512, L516, L520

Kit includes: Trigger, Trigger Cover, Trigger Pivot, Lower Lock Washer, Lower Cap, & Spring.



Mobile Tool Chest Spare Parts

