AUTO DRAIN VALVE - EXTERNAL - INTERMEDIATE

Product # **408892** | Model # **ADVI**



- As a standard, all JET filters have a manual drain valve fitted on them, however, this can be changed with an automatic drain valve fitted externally to the bowl
- The auto drain valve drains the condensate water automatically. In addition to automatic draining, there is also provision in the valve for manual drain off
- Unlike an electrical auto drain valve, these float type auto drain valve's operate only when the condensate is collected and drains only the condensate

TECHNICAL SPECIFICATIONS

Accessory (for use with Model Series)	AFI14, AFI38