PILOT BEARING SLIDE HAMMER PULLER

Product # **H1921** | Model #



- Slide hammer type
- Used for removing sleeve type bearings from 1/2" - 1-1/2" inside diameter on flywheels, pumps, and generators
- Turn the handle for quick adjustment and the center rod spreads the alloy steel jaws for a tight fit inside the bearings
- A few light taps with the sliding hammer, and the bearing is removed
- Optional Small Jaw H1921G